

## HYDRO ASSIST BRACKET FITTING GUIDE



Place the new bracket over your drop arm, some grinding may be required on your drop arm as it is cast and they do vary in size, insert bolts but do not tighten at this point. Insert spacer washer over the track rod end before inserting the track rod end through the drop arm this is here to centralise the track rod end in the bracket.



Once the track rod end is in place insert two 12 mm washers to centralise the track rod end in the top of the bracket.



Tighten all bolts at this point.



At this point the hydro assist ram can be fitted, please note the way the bolts are fitted through the bracket, if they are fitted the other way they could foul the drag link.

Check all bolts after the first couple of hours use.